



AMES ROOF REFERENCE GUIDE



PRODUCTS NEEDED

PROJECT	GOOD	BETTER	BEST	PREMIUM
Metal Roof	<ol style="list-style-type: none"> Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 1 coat of Blue Max on all seams, screw heads, and rusty areas at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 1-2 coats of Blue Max at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Apply Ames Peel & Stick Seam Tape on all seams Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 1-2 coats of Blue Max at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Apply Ames Peel & Stick Seam Tape on all seams Apply 2 coats of Premium Roof Armor at 1 gal/80 Sq. Ft per coat (10 mils DFT per coat)
EPDM	<ol style="list-style-type: none"> Apply 1-2 coats of Blue Max at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 2-3 coats of Blue Max at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 3 coats of Blue Max at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Embed polyester reinforcement fabric between the 1st & 2nd layers of Blue Max. The fabric should be fully saturated between 2 wet layers of product Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 3 coats of Blue Max at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Embed polyester reinforcement fabric between the 1st & 2nd layers of Blue Max. The fabric should be fully saturated between 2 wet layers of product Apply 2 coats of Premium Roof Armor at 1 gal/80 Sq. Ft per coat (10 mils DFT per coat)
Rolled Roofing Built-Up Roof Modified Bitumen	<ol style="list-style-type: none"> Apply 1-2 coats of Elasto Barrier at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat. (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 2-3 coats of Elasto Barrier at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat. (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 3 coats of Elasto Barrier at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Embed polyester reinforcement fabric between the 1st & 2nd layers of Elasto Barrier. The fabric should be fully saturated between 2 wet layers of product Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat. (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 3 coats of Elasto Barrier at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Embed polyester reinforcement fabric between the 1st & 2nd layers of Elasto Barrier. The fabric should be fully saturated between 2 wet layers of product Apply 2 coats of Premium Roof Armor at 1 gal/80 Sq. Ft per coat. (10 mils DFT per coat)
Tar & Gravel Roof	<ol style="list-style-type: none"> Apply 2 coats of Elasto Barrier at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat. (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 3 coats of Elasto Barrier at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat. (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 3 coats of Elasto Barrier at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Apply 3 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat. (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 3 coats of Elasto Barrier at 1 gal/100 Sq. Ft per coat (10 mils DFT per coat) Apply 2 coats of Premium Roof Armor at 1 gal/80 Sq. Ft per coat. (10 mils DFT per coat)
Concrete Roof	<ol style="list-style-type: none"> Apply 1 coat of Blue Max at 1 gal/100 Sq. Ft. (10 mils DFT per coat) Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat. (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 2 coats of Blue Max at 1 gal/100 Sq. Ft. (10 mils DFT per coat) Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat. (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 3 coats of Blue Max at 1 gal/100 Sq. Ft. (10 mils DFT per coat) Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat. (5.3 mils DFT per coat) 	<ol style="list-style-type: none"> Apply 3 coats of Blue Max at 1 gal/100 Sq. Ft. (10 mils DFT per coat) Apply 2 coats of Premium Roof Armor at 1 gal/80 Sq. Ft per coat. (10 mils DFT per coat)
RV Roof	 <ol style="list-style-type: none"> Ames Peel & Stick Seam Tape (Optional) Apply 1 coat of Blue Max at 1 gal/100 Sq. Ft per coat - (10 mils DFT per coat) Apply 2 coats of Maximum Stretch at 1 gal/100 Sq. Ft per coat - (5.3 mils DFT per coat) 			

NOTE: The number of base coats required depends on the condition of your roof. Maximum Stretch and Ames Premium Roof Armor are interchangeable for all roof types. However, Roof Armor provides enhanced long-term performance on flat roofs, offering superior UV stability and dirt resistance to stay brighter and whiter longer. This guide offers general recommendations and excludes preparation or detail work. For detailed application instructions, please contact an Ames product specialist.